





## Assembly and Operating Instruction



## Assembly and Operating Instruction







L=mm	W	VDC
562	1.9	12
762	2.6	
862	2.9	
962	3.2	

### Notes:

- Sensing distance: 2m
- Sensing angle: Max 120°
- Delay time: 30s





## Assembly and Operating Instruction **SF120**



- Notes:
- Sensing distance: 2m
  - Sensing angle: Max 120°
  - Delay time: 30s

L=mm	W	VDC
140	2.5	12

## Assembly and Operating Instruction **SF120**



- Notes:
- Sensing distance: 2m
  - Sensing angle: Max 120°
  - Delay time: 30s

L=mm	W	VDC
140	2.5	12